

LMMT/2-NFC Function Diagrams


Supply Initiated



Broyce Control Ltd., Pool Street, Wolverhampton, West Midlands WV2 4HN. England Tel: +44 (0) 1902 773746 Fax: +44 (0) 1902 420639 Email: sales@broycecontrol.com Web: www.broycecontrol.com E



Switch Initiated



Above function diagrams show one pole of output relay i.e. 15, 16 and 18 but can be applied to the second pole, 25, 26 and 28.

lssue 1 – 1219