


LMWVR Function Diagram

Under and Over voltage monitoring



LED Off
 LED On
 LED Flashing